Download area

Knock-in anchors with M 6 thread

Knock-in anchors are mainly used to secure mounting straps and fabric nailing tape. Our range includes anchors with an M6 thread, onto which clamp clips, for example, can be screwed. Suitable setting tools are shown on the following page.

SV



DIMENSIONS OF DRIVE-IN TIP IN MM	PACK QTY	CTN QTY	ARTICLE NO.
8 x 15	100	3,000	311101
8 x 18	100	3,000	311102
8 x 25	100	3,000	311103
8 x 30	100	3,000	311104
8 x 40	100	3,000	311105

HUP®

HUP Elektrotechnik Vertriebs GmbH
Hauptstraße 42
D-53809 Ruppichteroth-Winterscheid

Tel 0 22 47 - 91 25 50
Fax 0 22 47 - 91 25 52
Email info@hup-elektrotechnik.de

hup-elektrotechnik.de