



Vista general de herramientas dinamométricas

Herramientas	Precisión	Ajuste	Particularidad	Rango Nm	Rango dinamométrico					Varillas intercambiables
					0,01 Nm	0,1 Nm	1 Nm	10 Nm	20 Nm	
iTorque 	± 6 %	variable	Pantalla digital ClickControl Alarma de calibrado Escala numérica	0,4 – 1,5 0,8 – 3,0 1,0 – 5,0						Serie 2859    
TorqueVario®-S 	± 10 % ± 6 %/± 10 % ± 6 %	variable	Escala numérica	0,04 – 0,46 0,1 – 0,6 0,4 – 1,0 0,5 – 2,0 0,8 – 5,0 2,0 – 7,0						
TorqueVario®-S ESD 	± 10 % ± 6 %/± 10 % ± 6 %	variable	Compatible con ESD Escala numérica	0,04 – 0,46 0,1 – 0,6 0,4 – 1,0 0,5 – 2,0 0,8 – 5,0						
TorqueFix® 	± 6 %	ajuste fijo	Preajustado fijamente en fábrica	16 Versiones 0,4 – 7,2						
easyTorque 	± 10 %	ajuste fijo	Preajustado fijamente en fábrica	13 Versiones 0,5 – 5,0						
TorqueFix® Key 	± 6 %	ajuste fijo	Preajustado fijamente en fábrica	0,5 – 4,0						Serie 28369 
Adaptador easyTorque 	± 10 %	ajuste fijo	Certificado VDE Preajustado fijamente en fábrica	5 Versiones 0,8 – 4,0						slimBits Serie 2831   
TorqueVario®-S VDE 	± 6 %	variable	Certificado VDE Escala numérica	0,5 – 2,0 0,8 – 5,0 2,0 – 7,0						
TorqueVario®-S T electric 		variable	Certificado VDE Escala numérica	5 – 14						Serie 28379  
Llave dinamométrica electric 	± 4 %	variable	Certificado VDE Escala numérica	5-25						Serie 7207 (3/8") Serie 7209 (1/4")  
TorqueVario®-S T 	± 6 %	variable	Escala numérica	5,0 – 14						Serie 2899  
TorqueFix®-T 	± 6 %	ajuste fijo	Preajustado fijamente en fábrica	6 Versiones 6,0 – 14						